

Assembly instruction for washer bags – Linde 391, diesel version

1. Mark points for drilling using washer bags holes on truck frame.
2. Drill holes $\text{\O} 6,5$ in marked points.
3. Deepen holes by $\text{\O} 11$ drill.
4. Screw on the washer bags (1) by M6x20 screw (2) with metal-rubber washer.

